
Meridian Administration Tools

Call Tracking

User guide

Document Number: P0833800
Document Release: Standard 4.00
Date: June 1996

© 1996
All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

June 1994

Standard, release 1.0.

December 1994

Standard, release 2.0.

August 1995

Standard, release 3.0.

November 1995

Standard, pre-release 4.0a for testing.

February 1996

Standard, pre-release 4.00 for field trials.

May 1996

Standard, pre-release 4.00.

June 1996

Standard, release 4.00.

Contents

Introduction	1
Overview	1
MAT users	2
Conventions used in this manual	3
Getting Started	5
System access	5
Display	5
Graphical Displays	6
Data Supervisor	7
Running Call Tracking	8
Open Site	8
Set up Real Time connection	8
Collect from Data File	10
File Monitor Functions	13
File	14
Open Site	14
Close Site	15
Call Tracking ID Code	15
Schedule	15
Print	16
Print Setup	17
Reset	17
Reset Longest Call	18

Employee Database Options	18
Detail File	20
Pause	21
Exit	21
Real Time	21
Edit Database	21
Connect	24
Disconnect	24
Data File	24
Start File	25
End File	25
Pacing Factor	26
Filters	26
Filter Definitions	26
Include/Exclude Filters	29
Alarms	29
Alarm Definition	30
Alarm Setup	34
Alarm Log	41
Display	41
Help function	43
About Call Tracking	43
Graphical Displays	45
System Times	45
Recent Call History	46
Call Record Information	46
Current Call Information	47
User Defined Speedometer	47
User Defined Speedometer Alarm Setting	49
User Defined Speedometer Definition	50
Reset	53
Example setup	53
Percent Calls by Duration Graph	56
Call Origin Graph	57

Call Origin Pie Chart	58
Ring Time Meter	58
Average Ring Time Meter	59
Last Incoming Call Meter	59
Sample Setup for Real Time Monitoring	61
Sample scenario	61
Steps to connecting Call Tracking to Meridian 1	62
Step 1: Run MAT	63
Step 2: Verify communications parameters	63
Step 3: Run Call Tracking and Open Site	64
Step 4: Select communications parameters	64
Step 5: Ensure hardware connections	64
Step 6: Start Real Time monitoring	65

List of figures

Figure 1	
Communications Database dialog	9
Figure 2	
Call Tracking main window	13
Figure 3	
Open Site dialog	14
Figure 4	
Communications Database dialog	22
Figure 5	
Filter Definition dialog	27
Figure 6	
Alarm Definition dialog	30
Figure 7	
Alarm Setup dialog	35
Figure 8	
Recent Call History dialog	46
Figure 9	
User Defined Speedometer	47
Figure 10	
Alarm Title & Information dialog	49
Figure 11	
User Defined Speedometer Definition dialog	51
Figure 12	
Percent Calls by Duration Graph	57

Figure 13	
Call Origin Graph	57
Figure 14	
Call Origin Pie Chart	58
Figure 15	
Ring Time Meter	59
Figure 16	
Schematic for sample scenario	62